STRATA GATE FAULT GUIDE

If you have an automatic gate in a permanent open or closed position, use the following process to temporarily ensure continued access, secure the gate or restore operation.



